

M130 FAQs

Q: If I turn on the automatic record mode how often are values stored?

A: The current value is automatically stored every 5 seconds, for up to 20 minutes.

Q: At what point does the auto shutoff turn off the unit?

A: To conserve battery life, the M130 will automatically power off after 30 minutes of keypad inactivity.

Q: How much run-time is left when the BAT icon appears?

A: Approximately 2 hours.