Installation Instructions for meriLink™

Outline of the steps to install meriLink

1. Read these Installation Instructions first.

2. Check your computer's compatibility with Microsoft Windows.

3. Download and install the meriLink application.

Check your version of Microsoft Windows

The meriLink program is compatible with these versions of Windows.

- Windows 10

- Windows 8 (8.1)

- Windows 7

Download and install meriLink setup(.exe)

http://content.meriam.com/install/meriLink/setup.exe

Note: *Different browsers notify you in different ways when a file has downloaded and where to open it.*

1. Open the **setup** file and the following dialog box appears.
   Click **Run**.

   Note*: Some of you may see the full file name* **setup.exe***.*

2. After you click **Run**, the *meriLink Setup* dialog box appears, click **Install**.

3. Click **Install** again.

4. Click **OK**.

Congratulations. You are ready to use meriLink.

A shortcut for meriLink appears on your desktop.

Click to find the **9R609 meriLink User Manual** or go to the Products Manuals page on www.meriam.com to find the latest manual.

Error message: meriLink Setup

If this message appears, follow these steps:

1. Uninstall the existing version of **Microsoft Visual C++ 2015 Redistributable (x86) – 14.0.230.26** on your computer. See the figure below.

2. Open the Windows' Control Panel to find and uninstall this version of **Visual C++**.

3. Close the error window and reopen the **setup** file.

Help

Meriam Contact Information

Address

Meriam
10920 Madison Avenue
Cleveland | Ohio | 44102 | USA

Telephone

US customers	(800) 817-7849
International customers	+ 1 216 281 1100

Fax

US & International customers	+ 1 216 281 0228

E-mail addresses

Return Material Authorization / Service & Repair Department

returnforms@meriam.com

Sales

sales@meriam.com

Website

meriam.com

Find a local Meriam representative

Use this map to help you find a Meriam representative.

http://www.meriam.com/representatives-map/