

# PIT5000 Pipeline Integrity Tester





# PIT5000 Pipeline Integrity Tester



The PIT5000 from Meriam Process Technologies is a modern tool for conducting and documenting pipeline hydrostatic tests. Pressure, ambient temperature and pipeline temperature are measured by the system and plotted versus time on <u>one</u> graph.



## PIT5000 for Today's Testing Requirements



The Meriam PIT5000 Pipeline Integrity Tester is designed to significantly improve Pipeline Integrity Management over traditional hydrostatic pressure testing tools.

- Automatically collects NIST traceable pressure and temperature values versus time and saves the time stamped data to the PC hard drive
- Guarantees data consistency, eliminates transcription errors, prevents data manipulation during testing and produces an electronically secure final report
- Reduces operator work load allowing for focus on protecting the pipeline
- Provides unique rate information to monitor pressurization/depressurization and user-settable visual alerts active during the shut in period.



- Durable HPX resin case with built in wheels and telescoping pull handle, 3 handles for carrying or lifting
- Control panel organizes measurement device, minilaptop PC, switches and connections
- 12 hour or 28 hour sealed cell battery options
- 115V AC 50/60 Hz charger for system battery
- 30 ft DC extension cord with DC automotive plugs
- Charger or DC extension cord can be used to power the PIT5000
- Option for "no battery" is available for use where 115V AC or 12V DC power is readily available





- Mini-laptop PC with hydro-testing software, includes 4GB SD card
- Meriam MFT4000 with pressure module and two (2) RTD temperature modules
- 5,000 PSI pressure hose with quick test ends
- Two (2) Pt100, 4-wire RTDs, 1/4" diameter, 6" length, with cables
- Pump stroke counter and cable
- User selects PSI, kg/cm2, kPa, or bar pressure units as well as feet or meters length units



## Feature

- Electronic Pressure Sensing
- Pressure sensor wetted parts are all 316L SS
- NIST traceable accuracy: ±0.05% FS with no temp. effect from -20° to +50° C
- PIT5000 software records pressure vs time to hard drive file

## Benefit

- No need to spin weights or precisely level the instrument
- No problem using water in contact with sensor
- No need to density correct weights
- No charts or pens to change or replace. No linkages to slip.
  No pen lines to interpret



### Feature

- Tamb and Tpipe recorded vs time to same hard drive file
- •Real time plot of Pressure, Tamb and Tpipe vs. time on PC display
- Data sets (time, P, Tamb, Tpipe, stroke count and notes) saved each minute to file
- Stroke count vs time screen avoids overstressing pipe

## **Benefit**

- No circular charts or pens to change out
- •All test data on one display improves control while easing operator workload
- Secure MS Excel report provides detailed test information. Backup .csv is also saved
- Consolidates data collection to PC and saves to file



## Feature

• Stroke Count tab provides convenient data sets and strokes vs time graph

• MFT4000's Field Recalibration allows recertification by qualified local suppliers

## Benefit

- Automatic data collection for pressure, stroke count, and time plus graphic presentation reduces operator workload, allowing him to concentrate on protecting the pipeline.
- Flexibility in maintaining NIST traceability





PIT5000 software uses a convenient tab structure to allow user to select the area of interest. The Setup tab has sub-tabs for entering a complete set of information and test parameters prior to starting the test program.

Setup	St	rip Chart D	ata Detai	ls Stroke Co	unt		PIT5000
Test In	fo	Pump Info	Site Info	Test Limits	PC Setup	Manual	Version 1.0

The Setup / Test Info tab, shown on the next slide, provide entry for test information, units selection, etc...



### PIT5000 Software Screens – Setup/Test Info





# O PIT5000 Software Screens – Setup/Pump Info



The Pump Info sub-tab provides for entry of the pressure pump's model and serial numbers for record purposes.

If Stroke Count is not required, set the selection button to NO.

If Stroke Count is required, set the selection button to YES. Also enter the Volume Per Stroke, the desired Stroke Start Pressure and the Stroke Rate Target value. Note the test light button that allows confirmation of stroke count prior to starting the test program.



# PIT5000 Software Screens Setup/Pump Info



Setup St	trip Chart D	ata Detai	Is Stroke Co	unt		PIT5000	
Test Info	Pump Info	Site Info	Test Limits	PC Setup	Manual	Version 1.0	
F		e Count Re Yumber umber	quired <b>NO</b>				
1							Start Program
							End Test



# PIT5000 Software Screens Setup/Pump Info



Setup Strip Chart Data Details Stroke Count	PIT5000	
Test Info Pump Info Site Info Test Limits PC Setup Manual	Version 1.0	
Stroke Count Required Pump Model Number CAT-2S-5730 Pump Serial Number 094-345-732		
	p Contact th Closed	
	Start Progra	m
	End Test	

# PIT5000 Software Screens – Setup/Site Info



The Site Info tab provides entry for the High Point Pressure and for other test section elevations that may be necessary to meet documentation requirements.

Once this information is entered, the program automatically calculates the pressures at the other elevations including the pressure at the PIT5000 elevation. This pressure becomes the "PTest Instrument Pressure" on the Test Limits sub-tab.

Enter the length of the test section and pipe dimensions on this tab as well.



### PIT5000 Software Screens – Setup/Site Info





# PIT5000 Software Screens – Setup/Test Limits



The Test Limits sub-tab is for entry of Test Time, Maximum and Minimum pressure rate during pressurization phase and High and Low Limits on the PTest Instrument Pressure during test phase.

Some companies require a mini-leak test prior to going to higher pressures. Entry for this pressure value, labeled PLeak, is also provide here.

PTest Instrument Pressure is forwarded from the Site Info sub-tab.

Stroke Start Pressure, if stroke count is active, is forwarded from the Pump Info sub-tab.

## PIT5000 Software Screens Setup/Test Limits







### PIT5000 Software Screens – Setup/Test Limits





# PIT5000 Software Screens – Setup/PC Setup



The PIT5000 features National Institute of Standards and Technology (NIST) traceable certification on its pressure and temperature measurement devices. Certificates are shipped with each unit.

Open the Setup / PC Setup tab and click on "Get Cal Data" button to confirm measurement device model and serial numbers. This feature confirms that the PIT5000 is using the measurement devices documented by the NIST certificates and also confirms communication with the MFT measurement device.

## 

### PIT5000 Software Screens – Setup/PC Setup









Once all information is entered in the Setup sub-tabs, left click on the Start Program button, located on the lower right of the screen, to begin data collection and plotting data on the Strip Chart tab.

## PIT5000 Software Screens – Strip Chart





## Strip Chart – Scaling Y-Axes



- Temperature Y-axis is set to 0 150 deg F (-40 to +70 deg C). Scale end points can be changed by right clicking on the value and entering the new value.
- Auto-scaling of Time X-axis and Pressure Y-axis is standard in PIT5000 software; as time and pressure advance, the scale adjusts automatically
- To reset the scale end points of Pressure Y-axis to different values:
  - Move cursor over any Pressure-axis scale number and Right Click
  - Left click on the "Autoscale" menu option to remove the "check mark", deactivating the Auto-scaling from the Pressure-axis.
  - Move cursor over either scale end point value, left click, and change end point value to desired value.
  - Click anywhere on perimeter of display to finish.
  - Change the other end point if

**NOTE**: Do not fix the scale of Time X-axis or plot will not continue as the time proceeds.

### PIT5000 Software Screens – Strip Chart





# PIT5000 Software Screens Adding Notes



Operator notes can be added to the PIT5000 data file anytime after the Start Program button is selected. Locate and click on the "Add Note" text entry field (see graphic below, right) in the lower portion of the Data Panel. Type in the desired note, up to 60 characters in length.

When the note is complete, click the "Add Note" button. The note will be merged into the data file, along with its corresponding data set, for permanent record.

Notes can be reviewed on the Data tab at any time during the test.



# Reviewing Setup Sub-tabs after Program Start



Editable Setup information is locked out, but remains viewable, once the Start Program button is selected. To view Setup information after a test program is started, click on the Setup tab. Then click on the button located between the Stroke Count tab and the PIT5000 name block. Select the desired Setup sub-tab from the drop down box and view the grayed-out data on the display.







## •••

### PIT5000 Software – Setup Info after Start Program





## PIT5000 Software Screens - Stroke Count



The Stroke Count feature requires the user to provide a set of normally open, dry, electrical contacts from the positive displacement pump's stroke counter. Connect the factory supplied stroke count cable to the pump's dry contact set. The PIT5000 supplies +5VDC output to the dry contact set and counts pump strokes based on contact closures.

Beginning at the Stroke Start Pressure (from Setup / Pump Info sub-tab), the Stroke Count tab displays stroke data sets in tabular format and a live plot of pressure vs. pump strokes. In addition, three digital displays are provided: 1) Total Stroke Count, 2) stroke count recorded for previous 10 PSI increment (Counts A, next slide) and 3) running stroke count for the current 10 PSI increment period (Counts B, next slide). The virtual toggle switch automatically points to the active Counts window.

Users can input a "Double Stroke" value to activate colored alarm features in the Pump Contact bar.

## PIT5000 Software Screens Stroke Count



Setup	Strip Char	t Da	ata	Details	Stroke	Count	Test Limits 👻	PIT5000	PTest
	1122	Press	Stroke		Volume 1	000	and the second second filles and	and the second second	1780 PSI
378720	LI SLIST PM	1460	675	675		600-			Contractor and a second second
	01 3(12)49 PM	1470	35	710		700-			
	01.3(13)54 PM	1480	35	745		104100	البهوي المتنا للعولة والما		
3/8/20	11.3114154 PM	1490	34	779	105.1	600-			
	11.3:13:53 PM	1500	30	612		500-			
3/8/20	11.316(S1PM	1510	34	846	114.2	400 -			
3/8/20	11 3:17:53 PM	1520	35	681	118.9 1	300-			
3/8/20	IL BLESSEM	1530	34	515	123.5	200 -			
3/8/20	01.3:09:54771	1540	38	940	128,0 1	100-			Pressure Rate
3/6/20	11 3:20:51 PM	1550	35	503		000-	ي و و و و الجلا من الع وهود بيوود		DCT/Min
3/8/20	11 3:21:51 PM	1560	34	1017	107.0	900 -			10 PSI/Min
3/8/20	11 3122149 PM	1570	35	1052	142.0				Ambient Temp
3/8/20	11 323:54 PM	1580	34	1005		600-			vanorent remp
3/8/20	11 3124154 PM	1590	20			700-	الأولاك الالتي الأزاد ويهد وعده		73 Deg F
	11 3:25:53 PM	1600	35	1154	155.8	600 -			
3/8/20	11 3(26(54 PM	16191	34	188	160.4	500 -			Pipeline Temp
	11 3:27:53 PM	1620	33	1221	154.0	400 -			
3/6/20	11 3:26:54 914	1630	34	1255	159.4	300-			74 Deg F
3/8/20	11 3129154PM	1648	-35	1290		200 -			
	11.3:30:51 PM	1656	34	1324		00000	الألالة ولا بالإلا الإيالة والله والالا		
	IL HALSI PM	1660	33	1357	183.2	100 -			
	UTL 3532:49 PM	1670	35	1892	187.9	0-			
	11 3133154 PM	1680	34	1426	192.5	0 20		1400 1600 1600 2000	
	11 3:34:54 PM	1690	34	1460	197.1	100	Strokes	Contraction of the Contraction	
	11. 3:35:53 PM	1700	- 34	1496	201.7		Pump Contact		
	11 3336(54 PM	1710	35	1529	206.4		Tomp Concert		Add Note:
	11 3:37:53 PM	1720	34	1563	211.0	Doui	ble Stroke	Sec. 1	
	111 3138154 PM	1730	30	1597	215.4	1			C
the second s	11 3:39:54 PM	1740	35	1632	220.3	70			Begin Test
	11.314951 PM	1750	31	1666	224.9	Y -			segur rest
	01 3801:51 PM	1750	35	1761	229.4	Tota	Count Counts A	Counts B	
	11 3142149 PM	1770	31	1735	234.2		70 74	ETC.	End Test
3/8/20	01.3243254PM	1780	35	1770	239.6	17	70 34	71	citu rest

# PIT5000 Software Screens Data



The Data tab is available for viewing at any time. This tab provides tabular data sets taken at one minute intervals after the Start Program button is selected (unless modified on the Setup / Test Info / Data Interval value). Setting the Data Save Interval for 15 minutes would result in data sets each minute during pressurization phase, data sets every 15 minutes during test phase and data sets each minute during depressurization.

One data set consists of Time / Pressure / Ambient Temperature / Pipe Temperature / Stroke Count / Notes

# PIT5000 Software Screens Data



Setup	Strip	Chart Data	Details !	Stroke Count	Test Limits	PIT5000	PTest
Time		Pressure	Ambient Te	mp Pipeline Ten	ip Stroke Count	Notes	1830 PSI
9:05:2	4 AM	1279	69	64	1451		PTest High Limit
9:18:3	1 AM	1386	69	64	1693		1831 PSI PTest Low Limit
9:30:5	MA 8	1460	69	64	1793	PLeak test	1816 PSI
9:35:5	IO AM	1460	69	64	1793		
9:40:4	7 AM	1460	69	65	1793		a. 11
9:45:0	IS AM	1460	69	65	1793		Ambient Temp
9:45:2	4 AM	1460	69	67	1793	Start stroke	69 Deg F Pipeline Temp
9:56:3	I9 AM	1568	69	67	2071		69 Deg F
10:05	11 AM	1658	69	68	2283		U.S. Degr
10 14	24 AM	1745	69	68	2594		
10 25	30 AM	1830	69	68	2861		
10 26	36 AM	1830	69	68	2861		Add Note
10:27	35 AM	1830	69	69	2861		
10:28	38 AM	1830	69	69	2861	Start 8 hour	
			13			9	End Test

# PIT5000 Software Screens Details



The Details tab is available for viewing at any time. This tab provides a clock and the estimated test finish time (corresponding to the shut in pressure test duration) prior to Begin Test selection. After the Begin Test button is selected, a clock, start time and estimated test finish time is provided along with an elapsed timer.

The calibration data for the pressure and temperature measurement devices is also included on the Details tab.

The file path for both .csv and .xls files is shown on the Details tab.

## •••

### PIT5000 Software Screens – Details





### PIT5000 Software Screens – Test Complete







# PIT5000 Software End Program

To end a PIT5000 session, left click on "End Test" button at the lower right of any tab.

A confirmation question prevents accidentally ending a test in process.









The PIT5000 generates two report files:

1: \*.xls file contains all parameter labels, parameter values and measured information in tabular and graphic form for easy viewing. The data in this file is completely secure.

2: \*.csv file contains all parameter labels, parameter values and measured information. The information is listed line by line and is not formatted for easy viewing. This data can be mapped to the user's customer spreadsheet applications.

Note that the file name comes from the Setup / Test Info tab's "Test Name" field and has a date (MMDDYYY) and number code after it:

CSV Path	
C:\PIT5000\DATA\2011MontRelay002_08042011_1256.csv	
XLS Path	
C:\PIT5000\DATA\2011MontRelay002_08042011_1256.xls	



## PIT5000 Spreadsheet Report – Test Info



Division: Midwest		Area:	Zionsville		Location: M	iller		
Test Report Number:	2011-26-in	oh pretest-001		Date:	5/	12/2011		
Line Name & Number:	26*			Test Comple	eted By: Ja	iy Barker		
Valve Section:	From:	NA	To:	NA	Work Order			
Station Number:	From:	NA	To:	NA		Actual Te	est Pressurer	5
Length:	543 Feet				Minim	im	Max	imum
ANSI Rating:	600				1810 F			5 PSI
Test Name:	2011_26inc	h_pretest_00			Instructions	Number:	7T-234	
Reason for Test	New		Test Media:		Water		S.G.:	1
Inservice Date:	New		Discharge:		NA			
Pump Model Number:				al Number:				
Stroke Count Req:	No		Pump Strok		0.100GPM	Stroke	Start Press:	0 PSI
	-	End		pint				
	Upstream	Downstream		Low			T5000	
Pipe Elevation			0 Feet	0 Feet	PIT Elev.:		Test Max:	
Desired Maximum Pressure	1825 PSI	1825 PSI	1825 PSI	1825 PSI	PIT Press: 11	325 PSI	Test Min:	
PSI Rate Maximum	15 PSI/Min			iment Press:			Test Time:	8:00 Hours
PSI Rate Minimum	5 PSI/Min		PLeak Press	sure:	1540 PSI		Start Time:	9:18:54 PM
Calibration Information Bay #1	-							
Manufacturer: Meriam Instrum	ent							
Modell Number: G/GI3300								
Serial Number: 101020134								
Calibration Date - YYMMDD: 1	10217							



# PIT5000 Spreadsheet Report – Test Data Sets



85 Deg F	78 Deg F	0
85 Deg F	79 Deg F	0
85 Deg F	79 Deg F	0 pump shut down, start 8 hr test
85 Deg F	79 Deg F	0
85 Deg F	78 Deg F	0
		0
and the second second second		ō
		0
ALC: NOT THE REAL		0
and the second		0
and the second second second		0
CONTRACTOR OF A DESCRIPTION OF A DESCRIP		
the second se		0
		0
0.000 - 72.000		0
		0
and the second		0 bleed
		0
		0
		0 stop bleed
		0
		0
84 Deg F	77 Deg F	0
	85 Deg F 85 Deg F 85 Deg F 85 Deg F 86 Deg F 86 Deg F 86 Deg F 86 Deg F 86 Deg F 86 Deg F 85 Deg F	85 Deg F 79 Deg F 85 Deg F 79 Deg F 85 Deg F 79 Deg F 85 Deg F 78 Deg F 86 Deg F 78 Deg F 85 Deg F 77 Deg F 85 Deg F 77 Deg F 85 Deg F 78 Deg F 85 Deg F 78 Deg F 85 Deg F 77 Deg F 85 Deg F 78 Deg F 85 Deg F 78 Deg F 85 Deg F 78 Deg F 85 Deg F 77 Deg F 85 Deg F 78 Deg F 85 Deg F 85 Deg F 78 Deg F 85 Deg F 78 Deg F 85 Deg F 85 Deg F 78 Deg F 85 Deg F 85 Deg F 78 Deg F 85 Deg F



## PIT5000 Spreadsheet Report – Final Plot





## • • PIT5000 – Spike Testing



A spike test is a higher pressure, shorter duration variation of a hydrostatic pressure test. A spike test is normally performed prior to and in conjunction with a hydrostatic test.

The goal of a spike test is to expose pipeline flaws that otherwise grow and cause failure during the longer hydrostatic pressure test or during normal operational pressure cycles.

The PIT5000 software will document a spike test without any special set up or adjustments. See a sample plot on the next slide.



### PIT5000 – Spike Testing Sample Plot









Model			
ZPIT5000	Pipeline Inte	grity Tester	
	Battery		
	-00	No internal bat	tery. Run from supplied 115V AC charger or 12V DC extension
	-12		for PIT5000 devices, rechargeable from 115V AC or 12V DC
	-28		for PIT5000 devices, rechargeable from 115V AC or 12V DC
		Hose/Cable	
		Lengths	
		-00	No cables or hoses. Tester includes M12 RTD connections, M12 counter connection, 1/4" NPT(F)
			pressure connection
		-50	50 ft RTD cables, 150 ft counter cable, 1/4" NPT(F) pressure connection, NO PRESSURE HOSE
		-51	50 ft RTD cables, 150 ft counter cable, 50 ft pressure hose (5000 PSI rated), adapter fitting
		-150	150 ft RTD cables, 150 ft counter cable, 1/4" NPT(F) pressure connection, NO PRESSURE HOSE
		-151	150 ft RTD cables, 150 ft counter cable, 150 ft pressure hose (5000 PSI rated), adapter fitting
			Pressure
			Range
6	12 1		-1500 0 - 1500 PSIG, ±0.025% FS
	AR		-3300 0 - 3300 PSIG, ±0.05% FS



Example: ZPIT5000-12-151-3300